

IOGEAR GUWAVKIT2 Mac Driver installation

The zip file contains three drivers. Please unzip and install the Wireless USB driver according to your Mac OS version first.

Wireless USB Driver:

MacDrivers_10_5.dmg: for Mac OS X v10.5.8 (Leopard)

MacDrivers_10_6.dmg: for Mac OS X v10.6.4 (Snow Leopard)

When done, install the Displaylink video card driver

Video Driver :

DisplayLink_Video_1.6b2.dmg

Restart your computer to get the optimized result.