

## **GWPAP1 Firmware Upgrade Instructions**

1. Go to <https://www.iogear.com/product/GWPAP1/> and download the latest firmware.
2. Connect the NetShair Nano to your computer by plugging it into a USB port on your computer
3. Connect your computer to the NetShair\_Nano\_XXXX network.
  - a. Note: XXXX = last 4 digits of the NetShair Nano's MAC ID
4. Enter the default password "12345678" or the password that you have previously set. Click **OK** to connect.
5. Once the NetShair\_Nano\_XXXX Wi-Fi network is connected, open the browser and enter 192.168.1.254 in to the address bar to access the web client.
6. On the right menu bar, select **Management**.
  - a. Click on **Choose File** and select the downloaded firmware. Click **Upload** to begin the firmware upgrade process.
  - b. Note: DO NOT TURN OFF or disconnect the device during the firmware upgrade process. Device will automatically reboot after the upgrade.
7. After the reboot, you will need to reset your device. Keep the NetShair Nano connected to your computer.
  - a. Using a paper clip, hold down the reset button for 15 seconds. You can release the button after 15 seconds and wait for the device to reboot itself. The LED lights will turn off and turn back on. After this, you may connect back to the NetShair Nano Wi-Fi network.
8. Firmware upgrade is now complete.