



Federal Communications Commission (FCC) Statement

This product has been tested and found to comply with the limits for a Class B device, pursuant to part 15 of the FCC Rules. It is intended for use in residential setting, but may also be used in commercial or industrial setting.

CE Compliance

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (89/336/EMC), Low Voltage (73/23/EEC) and R&TTED (1999/5/EC).

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product
2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
3. Call the tech support line at 1-866-946-4327 (U.S. only) or 949-453-8782

Warranty Information

This product carries a 1 Year Limited Warranty.

For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-946-4327

Contact

Toll Free 866-946-4327 (USA)
Phone: 949-453-8782
19641 Da Vinci, Foothill Ranch, CA 92610

www.iogear.com
support@iogear.com

About Us



FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.

© 2010 IOGEAR®

IOGEAR®

QuickStart Guide

USB Smart Card Reader

GSR201
PART NO. Q1149




Package Contents

Start Here!

- 1 x USB Smart Card Reader
- 1 x Driver CD
- 1 x Quick Start Guide
- 1 x Warranty Card

Overview

1. Power status LED
2. Smart Card reading status LED
3. Smart Card slot
4. USB Type A Connector



Installation

Installing the Driver

Mac users do not need to install the driver. The Driver CD is only for Windows and Linux OS users.

Windows Driver Installation

1. Put CD into CD-ROM and Installer will auto run. Click "Yes" to install the driver.
If the Installer did not auto run, please go to "My Computer" → "CD-ROM" → "GSR201.exe"
2. Follow the installation guide and click "Finish"



Hardware Installation

1. Plug USB Smart Card Reader into the computer. The Windows OS will auto install the device.
2. Once the Power LED is on, the device is ready to use.

Important:

In order to protect your Smart Card, please remove Smart Card from Smart Card reader when not in use.

