

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product
2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
3. Call the tech support line at 1-866-946-4327 (U.S. only) or 1-949-453-8782

Warranty Information

This product carries a 3 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-946-4327

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model _____
Serial Number _____

Contact

IOGEAR

Address: 19641 Da Vinci, Foothill Ranch, CA 92618 USA
Toll Free: 866-9-IOGEAR
Phone: 949-453-8782
Web site: www.iogear.com
Email: support@iogear.com

About Us



FUN
IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN
IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.



© 2010 IOGEAR®



Quick Start Guide

USB 2.0 External HD Video Adapter

GUC2025H
Q1156

Package Contents

- 1 x USB to HD adapter
- 1 x USB Type A to mini-B cable
- 1 x Driver CD
- 1 x Quick Start Guide
- 1 x Warranty Card

Requirements

PC:

- Microsoft Windows® 7, Windows Vista® SP2 or Windows® XP (32-bit) SP3
- 1.6 GHz processor (CPU) with 1GB of system memory (RAM) with available USB 2.0 Port

Monitor:


- Flat-panel (LCD / Plasma / DLP) TV display or Projector with HDMI®. Does NOT work with CRT tube TV.
- TV or audio system with HDMI

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Product Overview

Start Here!


1. Power indicator
2. USB mini-B female port
3. DC Power Jack
4. HDMI® female port



Software Installation

Important! Do not connect the device to the PC before the software installation.

1. Insert the included CD to the CD-ROM/DVD-ROM of your computer. The installation process will automatically launch. Select the preferred language for the installation and click on "I Accept" to continue.
2. Restart the system if needed.



Hardware Installation


1. Connect the mini-B end of the included USB cable to the mini-B port on the USB External HD Video Adapter. Then connect the USB Type-A end of the cable to any available USB port on the computer. Once plugged in, the Installing Device Driver Message will come out and the Windows User Account Control window opens.

2. The device will be installed automatically.

3. User should be able to see the display icon on the task bar.

Note: On some computers, users may need to reboot before the user can use the device.

4. Connect the male end of the HDMI cable to the HDMI port on the USB External HD Video Card. Then connect the other male end of the HDMI cable to the HDMI port on the monitor/display.



Configuration

Users can configure USB External HD Video Adapter by clicking on the display icon.

Menu	Sub-Menu	Description
Updates	Check Now	Connects to the Update Server to check for latest driver versions and download them, if available.
	Configure	Opens the Update Options window where you can configure automatic updates.
Screen Resolution		Displays a list of available resolutions.
Screen Rotation	No rotation	No rotation
	Rotated Left	Rotates the extended or mirrored display by 270 degrees.
	Rotated Right	Rotates the extended or mirrored display by 90 degrees.
	Upside-Down	Rotates the extended or mirrored display by 180 degrees.
Extend To	Right	Extends the display to the right of the main display.
	Left	Extends the display to the left of the main display.
	Above	Extends the display to the above of the main display.
	Below	Extends the display to the below of the main display.
Extend		Extends your desktop onto the secondary display
Set as Main Monitor		Sets the secondary display as the main display.
Notebook Monitor Off		Switches off the display of an attached notebook and makes the external display primary.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications. Although this product complies with the limits for a Class B digital device, there is no guarantee that interference will not occur in a particular installation.

FCC Statement

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (89/336/EMC), Low Voltage (73/23/EEC) and R&TTE (1999/5/EC).