

## Limited Warranty

### WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at [www.iogear.com](http://www.iogear.com) to try and solve any issues you may be having with the product
2. Visit the Tech Info Library/FAQ on [www.iogear.com](http://www.iogear.com) (under the Support tab)
3. Call the tech support line at 1-866-946-4327 (U.S. only) or 949-453-8782

### Warranty Information

This product carries a 3 Year Limited Warranty.

For the terms and conditions of this warranty, please go to

<http://www.iogear.com/support/warranty> or call 1-866-946-4327

## Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications. Although this product complies with the limits for a Class B digital device, there is no guarantee that interference will not occur in a particular installation.

## CE Compliance

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (89/336/EMC), Low Voltage (73/23/EEC) and R&TTED (1999/5/EC).



### About Us



#### FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



#### GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.

## QuickStart Guide

Composite AV Cable with Charge & Sync  
for iPhone / iPod

## Requirements


## Start Here!

- TV or display with composite video port
- TV or stereo system with red/white analog audio ports
- iPhone 3GS, iPhone 3G, iPhone, iPod Touch 2G, iPod Touch, iPod Classic, iPod Nano, iPod Nano 4G, iPod 5G, or iPod Photo

## Package Contents

- |                          |                                |
|--------------------------|--------------------------------|
| 1 x iPhone/iPod AV Cable | 1 x Quick Start Guide          |
| 1 x USB Power Adapter    | 1 x Warranty/Registration Card |

## Device Overview



1. 30 pin connector for iPhone/iPod
2. RCA connectors, Yellow: Video, Red: Audio - Right, White: Audio - Left
3. USB connector: To sync your iPhone/iPod with your computer or charge via the included USB power adapter
4. USB power adapter: Power and charge your iPhone/iPod

## Hardware Installation

Note: Before you begin connecting devices, please turn down the volume on iPod or iPhone and turn off the power to all your components. Remember to make all connections firmly but never force a connector into a port if the connector and port do not join with reasonable ease.


- 1 Connect three RCA connectors of AV Cable into your TV's RCA AV input connectors. Be sure to match the connector color, Yellow - video, Red - right audio channel, and White - left audio channel.

Select the correct AV input source on your TV. For stereo audio receivers, please use two RCA connectors, red and white color only, for audio connection.

Note: Some TVs require both video and audio signal to be received together therefore you will not be able to play music only (no video) from your TV. Check with your TV's instruction manual for more details.

- 2 Plug the 30-pin connector into your iPhone or iPod. Open the application that supports video signal output, such as YouTube, Videos, iPod, or Slideshows in Photos. If the video does not appear on your TV, please go to Video setting in your iPhone or iPod, set "TV Out" to be "On" and choose "NTSC" or "PAL" TV signal to match your TV. Play video again to try. If still no video on the TV, please close the application and restart again.

Note: Please open the application after you connect your iPhone or iPod to your TV. If you play the video before connecting the device to your TV, the video may not be played properly on the TV. If you answer or reject a phone call during the video playback, you may need to open the application again to resume the video. Some power saving modes may also affect the video playback.



- 3 You may plug the USB connector into the included USB Power Adapter or your computer to keep your iPhone/iPod charged or synced.