

Quick Start Guide

MediaShair 2 Wireless Media Hub and Power Station

GWFRSDU2

PART NO. Q1328

This Quick Start Guide is intended to cover basic setup and key functions to get you up and running quickly.

For a complete explanation of setup and features, please download the MediaShair 2 User Manual from www.iogear.com

Package Contents

1 x MediaShair 2 Wireless Media Hub
1 x USB to Micro USB Cable





1 x Quick Start Guide
1 x Warranty Card


System Requirements

- Wi-Fi equipped wireless devices
- SD card or external USB storage device with media content
- Mobile devices require either Android 3.0+ or iOS 4.0+
- Wired or wireless network available for Internet connection when using optional Access Point feature*

*The MediaShair Hub can connect to a wired or wireless local network and use the built-in Access Point to share Wi-Fi Internet access to multiple wireless devices. Requires an Ethernet cable for access to wired networks, or the pre-shared security key for wireless networks.

Overview

1. Power button
2.  Internet indicator
3.  Wi-Fi indicator
Flashing Blue - Wi-Fi network restarting
Solid Blue - Wi-Fi network ready
4.  SD card indicator
5.  Battery charging indicator
Solid Green - Power on
Flashing Green - Media Hub is charging
Red - Battery low, recharge required
6. SD Card slot
7. Reset button
8. RJ-45 Ethernet port
9. USB port (also works as an emergency charging port)
10. Micro USB charging input



MediaShair Mode / Powerstation Mode

MediaShair Mode:

MediaShair mode is the normal operating mode which enables all features and functions of the device. The Powerstation mode (described in the next section) turns on only the charging output, and keeps the rest of the unit functions off to save power.

To turn on the MediaShair Hub and begin streaming your stored content:

1. Press and hold the power button for 5 seconds to turn MediaShair Hub on.
2. The green LED battery indicator will turn on.
3. The blue Wi-Fi indicator will begin flashing then light solid to indicate network is ready.
4. Connect to the MediaShair Wi-Fi network as shown for your device.

To turn off the MediaShair Hub:

Press and hold power button for 5 seconds to turn MediaShair Hub off.

Powerstation Mode:

The MediaShair Hub has a built-in Powerstation mode that can provide a quick boost to mobile devices such as smartphones or MP3 players in the event of an emergency. Please note that using the Powerstation mode can severely shorten the playback time when streaming media content.

If the MediaShair Hub is already on:

1. Plug the charging cable for your mobile device into the MediaShair Hub USB port.
2. The device will begin charging.

If the MediaShair Hub is off:

1. Plug the charging cable for your mobile device into the MediaShair Hub USB port.
2. Press the power button once to turn Powerstation feature on.
3. The green LED battery indicator will turn on and the device will begin charging.
4. When you are done charging, press the power button once to turn Powerstation feature off.

Recharging the MediaShair Hub

When the battery indicator turns red, the unit must be recharged. Connect the MediaShair Hub to nearly any USB wall charger such as those included with most smartphones and tablets. For convenience the MediaShair Hub can also be charged from any computer USB port, but due to the lower charging current of computer USB ports it may take longer to reach a full charge.

MediaShair Setup (iPod / iPhone / iPad)

1. Open the App Store on your iPod, iPhone or iPad. Search for the "**MediaShair 2**" app and download it to your device.
2. After installation is complete, the MediaShair 2 App icon will be shown on the device.
3. Press and hold the power button for 5 seconds to turn on the MediaShair Hub.
4. Open the **Settings** menu on your device and set Wi-Fi to **ON**.
5. Choose "**MediaShair-xxxx**" network.
6. Enter the default password "**12345678**" and tap **Join** to connect. Wi-Fi will display MediaShair-xxxx (-xxxx is the last four digits of the device's MAC ID).

MediaShair Setup (Android Devices)

1. Open the App Store on your Android device. Search for the "**MediaShair 2**" app and download it.
2. After installation is complete, the MediaShair 2 App icon will be shown on the device.
3. Press and hold the **Power** button for 5 seconds to turn on the MediaShair Hub.
4. Open the **Settings** menu on your device and set Wi-Fi to **ON**.
5. Choose "**MediaShair-xxxx**" network.
6. Enter the default password "**12345678**" and tap **Connect** to join. Wi-Fi will display MediaShair-xxxx (-xxxx is the last four digits of the device's MAC ID).

1. Insert a SD Card, USB Flash Drive or External Hard Drive with movies, music, photos or files.



2. Make sure the “MediaShair-xxxx” Wi-Fi network is connected.
3. Launch the MediaShair 2 app.
4. On the app home screen, tap the **File Manager** button and select the SD Card and/or storage device.
5. Tap the file you wish to access and playback will begin automatically.
Note: Only iOS supported formats can be played.

“Open With” (iPod / iPhone / iPad)

1. Press and hold movie file until list of 3rd party App appears
2. Choose desired App to play movie

Viewing MediaShair Content (Android)

1. Connect your USB Flash Drive or USB Hard Drive to the standard USB port.




2. Make sure the "MediaShair-xxxx" Wi-Fi network is connected.
3. Launch the MediaShair 2 app.
4. On the app home screen, tap the **File Manager** button to show the USB contents.
5. Tap the file you wish to access and playback will begin automatically.

MediaShair Setup (Laptop / Computer)


1. Press and hold the **power** button for 5 seconds to turn on the MediaShair Hub.
2. Click on the **wireless icon** on the bottom right corner of the computer screen.



3. Choose "**MediaShair-xxxx**" Network.



4. Enter the default password "12345678" and then press **OK** to connect.



5. Wi-Fi will display **MediaShair-xxxx Connected.**



Viewing MediaShair Content (Laptop)

1. Plug in a SD Card or connect your USB Flash Drive or USB Hard Drive to the USB port.
2. Make sure the "MediaShair-xxxx" Wi-Fi network is connected. Open the Browser, enter "10.10.10.254" into the web address bar and hit Enter.
To log in:
Default Username: **admin**
Default Password: **blank (no password)**
3. Click the **File Manager** and then select the storage device icon to browse the contents of the SD Card or USB device.
4. Select a folder to open, then click on the file you want to access. Playback will begin automatically.

Hotel Usage Explanation Note

A. Hotel provides wired Internet access

1. Press the power button to turn on the MediaShair Hub.
2. Connect your iPhone/iPad/Android Phone/Android Tablet/Laptop to the device through Wi-Fi (Note: if hotel requires user name & password for internet access, you must connect your device to the MediaShair Hub before you plug in the Ethernet cable!).
3. Connect the Ethernet cable in hotel to the WAN port of device.

B. Hotel provides Wi-Fi access

1. Press the power button to turn on the MediaShair Hub.
2. Connect your wireless devices to the MediaShair Hub through Wi-Fi.
3. Set MediaShair Hub to Wireless mode and choose a wireless network to connect.

Compliance Information

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications.

CE Compliance

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (2004/108/EC), Low Voltage (2006/95/EC) and R&TTED (1999/5/EC).

Declaration of Conformity and related documents can be downloaded directly from our website:

<http://www.iogear.com/product/GWFRSDU2/certifications>

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Visit www.iogear.com for more product information
2. Visit www.iogear.com/support for live help and product support

Warranty Information

This product carries a 1 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty>

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model _____

Serial Number _____

Contact

iogear.custhelp.com

support@iogear.com

www.iogear.com

19641 Da Vinci, Foothill Ranch, CA 92610