



Quick Start Guide

2/4-Port 4K DisplayPort KVMP Switch with
Dual Video Out and RS-232

GCS1932M/GCS1934M/GCS1932MX/GCS1934MX
PART NO. Q1499/Q1500

Package Contents

1

GCS1932M / GCS1934M

- 1 x GCS1932M / GCS1934M
- 2 x DisplayPort 1.2 Cables / 4 x DisplayPort 1.2 Cables
- 2 x USB 3.0 Cables / 4 x USB 3.0 Cables
- 2 x Audio Cable Sets / 4 x Audio Cable Sets
- 1 x Power Adapter
- 1 x Quick Start Guide
- 1 x Warranty Card

GCS1932MX / GCS1934MX

- 1 x GCS1932M/ GCS1934M
- 1 x Power Adapter
- 1 x Quick Start Guide
- 1 x Warranty Card

System Requirements

Console:

- DisplayPort monitor and/or HDMI monitor
- Standard wired USB keyboard
- Standard 3-button wired USB mouse
- Speakers and Microphones (optional)

Computer:

- DisplayPort port*
- USB Type-A port
- Audio ports (optional)


Operating Systems:

- Windows® 2000, Vista, 7, 8.1, 10
- Mac OS X 9.0+
- Oracle® Solaris
- Linux®, UNIX, and other USB supported systems


*MST requires PC Source to be DisplayPort1.2 MST compliant.
DisplayPort 1.1 source will result in mirror viewing.

Overview

GCS1932M Front View




GCS1932M Rear View




- A. Port selection pushbuttons
- B. Port LEDs
- C. Analog 2.1 Audio (Speaker and Microphone)
- D. USB 3.0 Hub
- E. Console Ports
- F. KVM Ports
- G. Power Jack

GCS1934M Front View




GCS1934M Rear View




1. Connect the USB keyboard and mouse to the GCS1932M/GCS1934M console ports
2. Connect the DisplayPort and/or HDMI monitor to the GCS1932M/GCS1934M console ports
3. Turn the monitor power to ON
4. Connect the main microphone and speakers into the GCS1932M/GCS1934M microphone and speaker jacks located on the front side panel. (optional)
5. Connect the secondary microphone and speakers into the GCS1932M/GCS1934M microphone and speaker jacks located on the rear side panel. (optional)
6. Connected the DisplayPort connector (not included in GCS1932MX/GCS1934MX models) into any available DisplayPort port in the KVM Port section. Connect the USB, microphone, and speaker connectors (not included in the GCS1932MX/GCS1934MX models) into the GCS1932M/GCS1934M. Connect the other end of the KVM cables to their respective DisplayPort, USB, microphone, and speaker ports on the computers.
7. Connect up to 2 USB peripherals into the USB 3.0 Type-A ports (front and rear panel of the GCS1932M/GCS1934M)
8. Connect the power adapter to an AC power source. Then, connect the power adapter cable to the GCS1932M/GCS1934M power jack.
9. Turn all connected computers power to On

Hardware Installation


GCS1932M Rear View




GCS1932M Front View



GCS1934M Rear View



GCS1934M Front View



Operation

Switch Operation

Switching between connected computer sources:

- a. Manual – involves pressing the port selection pushbuttons located on the GCS1932M/GCS1934M's front panel.
- b. Hotkey – involves entering combinations from the keyboard (list of complete Hotkey Settings is available in the manual, located on our website).
- c. Mouse – involves clicking the mouse wheel button twice to switch between ports (mouse emulation must be on, please see manual for a complete Hotkey Settings).

Display Settings

- a. DisplayPort 1.1 Source – 2 monitors will be in mirror mode
- b. DisplayPort 1.2 with MST Support Source – 2 monitors will be in mirror or extended mode

For a list of complete Hotkey Settings, please visit our website for updated manuals:

www.iogear.com/product/GCS1932M

www.iogear.com/product/GCS1934M

EMC Information

Federal Communications Commission Statement (FCC) Statement:

This equipment has been tested and found to comply with the limits for a Class B digital service, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Limited Warranty

This product carries a 3 Year Limited or Lifetime Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty>

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model

Serial Number _____

Contact

WE'RE HERE TO HELP YOU!
NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Visit www.iogear.com for more product information
2. Visit www.iogear.com/support for live help and product support

IOGEAR

iogear.custhelp.com

support@iogear.com

www.iogear.com