

A solid green vertical rectangular bar.

Quick Start Guide

Wireless Screen Sharing

GWAVRC

PART NO. Q1542-c

© 2020 IOGEAR® Part No. Q1542-c

IOGEAR, the IOGEAR logo, are trademarks or registered trademarks of IOGEAR. Microsoft and Windows are registered trademarks of Microsoft Corporation. All other brand and product names are trademarks or registered trademarks of their respective holders. IOGEAR makes no warranty of any kind with regards to the information presented in this document. All information furnished here is for informational purposes only and is subject to change without notice. IOGEAR assumes no responsibility for any inaccuracies or errors that may appear in this document.

Table of Contents

Introduction	4
Features	4
Package Contents	5
System Requirements	5
Overview	6
Hardware Installation	7
Installation for Samsung tablets and phones with SmartView	9
Windows® 10	12
Compliance Information	17
Limited Warranty	17
Contact	17

Introduction

IOGEAR's Wireless Screen Sharing kit allows you to enjoy all of your personal and online content wirelessly on your big screen HDTV. Using your Samsung Smart View, tablet or Windows® 10 computer, you can sit back and experience your favorite movies, videos, photos, online shows and more in Full HD on your HDTV with great image, clarity and sound.

Note: For a list of known Miracast-certified devices, please visit:
<http://www.wi-fi.org/discover-wi-fi/wi-fi-certified-miracast>

Features

- Wirelessly send your favorite videos, photos, music and Internet content from your Smart Phone, Tablet or Laptop to your HDTV, HD Projector or HD Display
- Full HD 1080p video resolution playback support
- Works with Miracast™ certified devices
- Ideal solution for sharing PC content wirelessly at Home, at the Office and in the Classroom

Package Contents

- 1 x Wireless A/V Receiver
- 1 x Power Adapter
- 1 x Micro USB Power Cable
- 1 x HDMI Cable
- 1 x Quick Start Guide
- 1 x Warranty Card

System Requirements

PC (Minimum Requirements)

- Intel Core i5 4th Gen or AMD Phenom II X4 equivalent or newer
- 8GB or more of system memory (RAM)
- Wireless networking capability

Operating Systems

- Windows® 10

Smartphones and Tablets

- Wi-Fi Miracast™ certified
- Samsung Phones and tablets with Smart View
- Windows® 10 or later* PCs and tablets

Display


- HDTV or Projector with HDMI port

*This product will not work with Android 6 (Marshmallow) and above or Apple iOS & Mac OS

Overview

Receiver:


- A. Power LED
- B. HDMI Out (to TV)
- C. Firmware upgrade Switch
- D. USB Micro-B Power Port




Hardware Installation

Set up the Wireless A/V Receiver

1. Connect one end of the included HDMI Cable into an available HDMI input on your HDTV or HD Projector.
2. Connect the other end of the HDMI cable to the HDMI port on the Wireless A/V Receiver.
3. Plug the Micro USB end of the Power Cable into the USB-Micro B power port on the Wireless A/V Receiver.
4. Plug the other end of the USB Power Cable into the USB Power Adapter included in the package. Then plug the USB Power Adapter into an available power outlet.
5. The Power LED will light solid blue.



6. Turn on your TV or projector, and make sure you select the correct video input that you connect your GWAVRC receiver to. The IOGEAR flash screen will come up on the display and on the top left of the screen will be the device name IOGEAR-xxx.





Installation for Samsung tablets and phones with SmartView


Most Samsung mobile devices supports mirroring screen from the devices to the IOGEAR receivers, then to the TV. It is done by swiping down from the top and select Smart View on the phone. The phone will go out and look for any Miracast supported devices you can find these options under Screen or Display options, with terms like Screen Mirroring, or Smart View”.

Android devices

1. On your Home screen. Using your finger, swipe down from the top of the screen and a menu will appear. From this menu choose “Smart View”.



2. Your device will start searching for the Wireless A/V Receiver. Once the receiver appears, tap on it to connect.




3. After you initiate the connection, wait a few seconds for your device to establish the connection with the wireless receiver.

When a black screen displays on both the TV and your device, the connection has been established. The technical term for this is “sync”, and the two devices have now synced with each other.


After a connection is established you should be able to see a mirror image of your device on the big screen TV; whatever you do on your mobile device will be duplicated on the big screen from this point and on.

To disconnect from the TV, you can either turn off your device or disconnect from the Display options screen by swiping down on the screen again and click on Smart View again, this will disconnect your phone from the display (TV).




Windows® 10


For computers with Windows® 10 you can hold down Windows® key + “p” or go to “Setting” and choose “Display”. If you see an option for “Connect to a wireless display”, your computer is Wi-Fi Direct ready.



If you see the above screen, click on “Connect to a wireless display”. Windows® will now search for the GWAVRC, the name will be IOGEAR-xxxx.




Click on the name IOGEAR-xxxx and connection will initiate. Give a few seconds, the TV or projector will change to the exact same screen as your Windows® 10 computer.





Once you have established connection Windows will mirror your content to the big screen. This screen will indicate that the connection is now established and you can click on “Disconnect” when you no longer want to mirror to your TV.

To disconnect, simply click on “Disconnect” and Windows will terminate the connection.





As an alternate way to connect to the GWAVRC, you can also click on “Message” at the bottom right of your screen, click on “Expand” and then “Project”. Below will be the screens you will see after you click on “Project”






Once you click on “Project” you can select how you want to connect to your TV screen and click on “Connect to a wireless display”





Click on the IOGEAR-XXXX to connect.

An alternate way to disconnect is by clicking “Disconnect” from the drop down menu on top of your screen. To hide/unhide the dropdown menu just click on the pin. Once the dropdown menu disappears, to view it again just move your mouse pointer to the top of the screen.



Compliance Information

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications. Although this product complies with the limits for a Class B digital device, there is no guarantee that interference will not occur in a particular installation.

Limited Warranty

This product carries a 1 Year Limited Warranty. For the terms and conditions of this warranty, please go to <https://www.iogear.com/support/warranty>

Register online at <https://www.iogear.com/register>

Important Product Information

Product Model _____

Serial Number _____

Contact

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Visit www.iogear.com for more product information
2. Visit www.iogear.com/support for live help and product support

www.iogear.com | <https://iogear.custhelp.com> | support@iogear.com

[illegible]

