IOGEAR®

Quick Start Guide
Duplicast Wireless
Screen Mirroring Transmitter

GWAVRTX
PART NO. Q1395

Package Contents

1 x GWAVRTX Wireless USB Transmitter
1 x Quick Start Guide
1 x Warranty Card

Note: Only one GWAVRTX is included
Required: IOGEAR Duplicast Wireless Screen
          Mirroring (GWAVRB)

Overview

Transmitter
• USB Type-A Connector

PC (Minimum Requirements)
• Intel® Core™ i5 2nd Gen
  or
  AMD® Phenom™ X4
• 4GB of system memory (RAM)
• Available USB Port

**Operating Systems**
• Windows® 7, Windows® 8.1, Windows® 10

Display
• HDTV or Projector with HDMI® port

1. Close all other applications.

2. **Connect the Wireless USB Transmitter to an available USB port on your PC.**

3. Please go to https://www.iogear.com/support/dm/driver/GWAVRKIT, select your operating system and download the Driver/Software and select the location where you want to put the file.

4. Once download is finished, go to the location where you put the file (by default this will be in your Downloads folder).

5. Go to your **Downloads** folder.

6. Double click on the **Setup.exe** Application file.

7. An installation menu will appear, select
   Duplicast Installation.

Duplicast Installation

Exit

$\hat{Q}$*IOGEAR*

8. The **Select Setup Language** box will
   appear. Select the preferred language
   from the dropdown menu and click **OK**.

9. The Welcome window will launch. Select **Next**.

10. The Select Destination window will appear.
    Click **Next**. Press the **Browse**… button to
    choose a different file destination.

11. Select **Next** on the Select Start Menu
    Folder screen.

12. On the Preparing window, click the
Install button.

13. Installation process will begin and will take you to the **Finish** screen where you will be prompted to restart your computer. Click **Finish** to complete the installation and restart your PC.

Pairing an Additional Wireless USB Transmitter to the Duplicast Wireless Receiver

IMPORTANT NOTE: Remove any active Duplicast Wireless Screen Mirroring Transmitter(s) before proceeding further with setup.

1. Connect the additional Wireless USB Transmitter to an available USB port on your PC.

2. If the transmitter has not been paired to the PC before, the following message will display. Select **Yes** to continue.

3. The below prompt will appear to inform that the pairing process has been completed. Click **OK** to proceed.

4. Restart Duplicast by double clicking on the Duplicast icon from the Desktop.

5. Pairing Wizard will launch. Select "GWAVRK xxx" from the dropdown menu and click **Ok**.

Pairing Wizard	
Name:	Duplicast Wireless Transmitter
AP List:	GWAVRK 240 ⌄ 🔄
☑ Auto Play	
☑ Use 5G	
	Ok Cancel

6. Wireless screen mirroring will begin. Repeat steps 1-6 for connecting additional Wireless USB Transmitters.

Compliance Information

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications. Although this product complies with the limits for a Class B digital device, there is no guarantee that interference will not occur in a particular installation.

CE Statement

This device has been tested and found to comply with the following European Union directives: Electromagnetic Capability (2004/108/EC), Low Voltage (2006/95/EC) and R&TTED (1999/5/EC).

Limited Warranty

This product carries a 1 Year Limited Warranty. For the terms and conditions of this warranty, please go to http://www.iogear.com/support/warranty

Register online at http://www.iogear.com/register

Important Product Information
Product Model _____
Serial Number _____

Contact

WE'RE HERE TO HELP YOU!
NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:
1. Visit www.iogear.com for more product information
2. Visit www.iogear.com/support for live help and product support

IOGEAR
iogear.custhelp.com
support@iogear.com
www.iogear.com