

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential setting. This product generates, uses, and can radiate radio frequency energy and, if not installed and used as directed, it may cause harmful interference to radio communications. Although this product complies with the limits for a Class B digital device, there is no guarantee that interference will not occur in a particular installation.

CE Compliance

This device has been tested and found to comply with the following European Union directives: Electromagnetic Compatibility (89/336/EMC), Low Voltage (73/23/EEC) and R&TTE (1999/5/EC).

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:
1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product.
2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
3. Call the tech support line at 1-866-946-4327 (U.S. only) or 1-949-453-8782

Warranty Information
This product carries a 3 Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-946-4327

Register online at <http://www.iogear.com/register>

Important Product Information

Product Model: _____
Serial Number: _____

Contact

IOGEAR
Address: 19641 Da Vinci, Foothill Ranch, CA 92618 USA
Toll Free: 866-9-IOGEAR
Phone: 949-453-8782
Web site: www.iogear.com
Email: support@iogear.com



Quick Start Guide

2.4GHz Wireless Compact Keyboard with Optical Trackball and Scroll Wheel

Package Contents

1 x 2.4GHz Wireless Keyboard
1 x USB RF Receiver
2 x AAA Alkaline Battery
1 x Quick Start Guide
1 x Warranty Card

Requirements

Computer / Device*
• 1 USB port

Operating System
• Windows XP
• Windows Vista (32-bit / 64-bit)
• Windows 7 (32-bit / 64-bit)
• Mac OS X v10.5.9 or later**

*Device must support USB HID keyboard device and USB HID-compliant mouse in order to have the keyboard and mouse function correctly respectively.
**Some Mac special keys may not work

About Us



FUN
IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.

GREEN
IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.

GKM681R
Q1155

1

Overview

Start Here!

Keyboard – Front View

- Media Player
- Volume Up
- Volume Down
- Mute
- Web Browser
- Previous Page
- Next Page
- Stop
- Refresh
- Search
- E-mail
- Battery Low LED
- Optical Trackball
- My Computer
- Play/Pause
- Previous Track
- Next Track
- Stop
- Scroll Wheel
- Mouse Left-Click
- Mouse Right-Click




Keyboard – Side View

- Mouse Right-Click
- Mouse Left-Click



Keyboard – Bottom View

- Battery Cover
- USB RF Receiver
- Connect Button



2

3

Installation

Step 1

Open the battery cover on the bottom of the keyboard and insert the 2 included AAA batteries into the battery tray and close the battery cover. Then, take out the USB RF receiver on the bottom of the keyboard.



*Note: Please make sure the batteries are installed properly as the directions inside the battery tray.

Step 2

Connect the USB RF receiver into any open USB port of your computer/device*.

*Device must support USB HID keyboard device and USB HID-compliant mouse in order to have the keyboard and mouse function correctly respectively.

Step 3

Now the keyboard should be ready to use. If the keyboard or trackball does not response, please see Pairing section for details.

Pairing (Optional)

The keyboard and mouse should be working properly without the need to pair. If the keyboard and mouse are not working, please follow the below instruction to pair the USB RF receiver and the keyboard.

Note: Please keep the distance between the keyboard and USB RF receiver as close as possible when pairing. The keyboard will connect to the closest USB RF receiver if there are more than 1 set of this keyboard within the same area.

Press the Connect button on the bottom of the keyboard while the USB RF receiver is connected to the computer/device*.

Now the keyboard and mouse should be working properly. If the keyboard and mouse are not working, please repeat the above instruction.

*Computer/device must be powered on

Sleep Mode

After the keyboard is idle for 30 minutes, it will go into sleep mode to save power. To wake it up, simply press any key on the keyboard.

4

Function Keys

There are a total of 7 sets of function keys in this keyboard. Simply press and hold the [Fn] button, then press the specific function key to trigger the function key. Please see the below function key list for detail.

Normal Function Keys

Function Key	Description
F11	F11
F12	F12
Sc Lk	Scroll Lock
PgUp	Page Up
PgDn	Page Down
Home	Home
End	End

Multimedia Hotkeys

Hotkey	Function	Description
[Web Browser Icon]	Web Browser	Launch default web browser. If the web browser window is already opened, then it will load the default homepage
[Previous Page Icon]	Previous Page	Go to the previous webpage
[Next Page Icon]	Next Page	Go to the next webpage
[Stop Icon]	Stop	Stop loading the webpage
[Refresh Icon]	Refresh	Refresh webpage or windows content
[Search Icon]	Search	Open the explorer search window
[E-mail Icon]	E-mail	Launch the default e-mail program
[Media Player Icon]	Media Player	Launch the default media player
[Volume Up Icon]	Volume Up	Increase the volume by 1 level
[Volume Down Icon]	Volume Down	Decrease the volume by 1 level
[Mute Icon]	Mute	Enable/disable audio mute
[Play/Pause Icon]	Play/Pause	Play/pause media in media player
[Previous Track Icon]	Previous Track	Skip to previous track in media player
[Next Track Icon]	Next Track	Skip to next track in media player
[Stop Icon]	Stop	Stop media in media player

5